CL306 – Leeda Digital Timer

Operating Instructions

The CL306 Digital Timer has four switches on the back:

1. Power On/Off Switch
2. Vibrate and Soft Beep On/Off Switch
3. Flashing LED On/Off Switch
4. Loud Beep On/Off Switch
5. 2, 3 and 4 refer to the alarm type. You may choose any combination of the three

Count Down Mode:

1 Hold the 'MIN' and 'SEC' buttons at the same time to zero the timer
2 Press the 'MIN' button to increase the minutes
3 Press the 'SEC' button to increase the seconds
4 The maximum time for the CL306 Digital Timer is 99:59
5 Once the desired time is reached, press the 'Start/Stop' button to start the timer
6 To pause the timer, press the 'Start/Stop' button
7 When the timer reaches zero it will Vibrate/Beep/Flash (depending on which setting you have chosen)

Count Up Mode :

1 Hold down the 'MIN' and 'SEC' buttons at the same time to zero the timer
2 Press the 'Start/Stop' button to start the timer. The maximum time the counter with count to is 99:59
3 To pause the timer, press the 'Start/Stop' button. Press it again to restart the timer