

## CL302 – 24-Hour Electronic Timer-Clock

### Operating Instructions:

#### Setting the Clock:

- 1 Slide the switch on the left hand side to 'CLOCK'
- 2 Press the 'HR', 'MIN' and 'SEC' buttons to set the time
- 3 Hold the 'CLEAR' button for 3 seconds to change from 12-hour to 24-hour format

#### Count-Up Setting:

- 1 Slide the switch on the left hand side to 'COUNT-UP'
- 2 Press the 'START/STOP' button to start
- 3 Press the 'START/STOP' button to pause
- 4 Press the 'CLEAR' button to reset

#### Count-Down/Timer Setting:

- 1 Slide the switch on the left hand side to 'TIMER'
- 2 Press the 'HR', 'MIN' and 'SEC' buttons to set the time (Maximum of 23hrs, 59mins and 59secs)
- 3 Press the 'START/STOP' button to start
- 4 Press the 'START/STOP' button to pause
- 5 Press the 'CLEAR' button to reset

#### Memory Function:

If you frequently use the same count-down time, you can store it.

- 1 Slide the switch on the left hand side to 'TIMER'
- 2 Press the 'HR', 'MIN' and 'SEC' buttons to set the time (Maximum of 23hrs, 59mins and 59secs)
- 3 Press the 'MEMORY' button to pre-set your desired time
- 4 To cancel the pre-set time press the 'CLEAR' button when the memory icon is displayed on the LCD display